Terminal for fitting PC board at free angle

RF series (1set/pack)

- This is a metal fitting for changing the angle of slave board on a PC board by 15 degrees at a time from 0 degree to 90 degrees.
- Please solder and fix the soldering side base to the PC board. Then, please set the
 metalfitting for PC board to the desired angle and tighten a screw.
 After that, please fit the slave board by using a screw.
- Two types (M3 and M4) are available for the slave board fitting side.

Material: BrassFinish: Nickel plating



■ Part No.


Part No.	M
RF-50-M3	M3 P=0.5
RF-50-M4	M4 P=0.7


• 1 set for the left and right is included in 1 pack.

■ Example of usage



■ Dimension






Part No.	(D)	M
RF-50-M3	2.2	M3 P=0.5
RF-50-M4	2.4	M4 P=0.7

- ① M4 sems screw (L=8)
 (with spring washer and flat washer)
- * 1 set is the two pieces of item that is symmetric to the shape shown in the drawing.

Recommended land information



Reference dimensions of the slave board design

